


silent block led

SB LD H60, SB LD P60, SB LD P105, SB LD R60, SB LD R120,
SB LD R120H, SB LD RC120, SB LD S60, SB LD S120, SB LD T120

installation manual




bejot:

people




additional tools




parts


1




2




3



attached





x2






x2

* - not added for assembly,
parts suitable for the ground


1






2







3







3




4



5




6




7

dimensions


SB LD H60




SB LD P60




SB LD P105




SB LD R60




SB LD R120




SB LD R120H




SB LD RC120




SB LD RS60



SB LD S120



SB LD T120



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznań, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 11/2021